

### Model 57-1200MAG

## IN THE BOX


Make sure you have everything shown here.



Mag Lock





Armature



**IMPORTANT!** (!)

> Specific mounting brackets are required for certain types of gate/door installations. These brackets are sold separately.





57-BRA1200APH

- 1. Hex Bolt
- 2. Rubber Washer (2x)
- 3. Washer (2x)
- 4. Guide Pin (2x)
- 5. Door Spacer
- 6. L Key
- 7. 60-mm M6 Mounting Screw (4x)
- 8. 40-mm M6 Mounting Screw (4x)
- 9. 60-mm M6 Mounting Screw (4x)
- 10. 50-mm M6 Mounting Screw (4x)

## **INSTALLATION**

1. Determine type of gate or door you have. (Refer to Gate/Door Types on next page.)

#### NOTE: Specific mounting brackets are required for certain types of gate/door installations. See above.

- 2. Determine desired location for mag lock and armature on gate post, and prepare post for mounting mag lock and armature, ensuring there is space for wiring.
- 3. Remove rubber plugs from necessary holes, and mount mag lock in required orientation using screws suitable for particular installation. (See Figures 1 and 2.)
- 4. Mount armature. (Refer to Armature Installation.)
- 5. Verify proper alignment by closing gate/door and verifying that mag lock and armature make full contact over entire armature length. Adjust as needed.
- 6. Wire mag lock. (Refer to Wiring Diagrams.)
- 7. Test mag lock for correct operation.

NOTE: Do not complete the last step of installation until you have verified everything is working as required. Removal of the rubber plugs can be difficult.

8. Place rubber plugs into mounting screw access holes on mag lock.




Figure 1: Orientation A





Figure 2: Orientation B

# **INSTRUCTIONS** MAG LOCK 1200

## **GATE/DOOR TYPES**



© 2024 Security Brands, Inc. All rights reserved.

I-571200MAG-EN Rev. A (1/2024)