



WIRING GUIDE

RemotePro CR with Intercom (23-XXXI) to Third-Party Base Station

NEED HELP


Call (972) 474-6390

Email techsupport@securitybrandsinc.com

We are available **Mon-Fri / 8am-5pm Central**



23-XXXI




CAUTION

Connect the capacitor as shown. Do not let the capacitor touch the yellow wire.

Failure to connect the capacitor correctly can damage the unit!

Base Station



Refer to base station manual for wiring requirements.

To Gate Operator
Open Input

SECURITY BRANDS INC.
your *partner* in access control